Outline

- Analysis of the sample and hold
- Pourier transform
- 3 Spectrum of a sampled signal
 - Aliasing
 - Sampling theorem
 - Hidden oscillations
- 4 Data extrapolation (reconstruction)

Hidden oscillations

There is the possibility that a signal could contain some frequencies that the samples do not show at all.

Such signals, when they occur in digital control systems, are called **hidden oscillations**.

They can only occur at multiples of the Nyquist frequency (π/T) .


Outline

- Analysis of the sample and hold
- Pourier transform
- Spectrum of a sampled signa
 - Aliasing
 - Sampling theorem
 - Hidden oscillations
- 4 Data extrapolation (reconstruction)

Reconstruction

<u>Sampling theorem</u>: *under* the right conditions it is possible to recover a signal from its samples.

The figure to the right shows the spectrum of $R(j\omega)$. It is contained in the low-frequency part of $R^*(j\omega)$. Therefore, to recover $R(j\omega)$ we need to process $R^*(j\omega)$ through a low-pass filter and multiply by T.



Reconstruction

If $R(j\omega)$ has zero energy for frequencies in the bands above the Nyquist frequency, in other words R is band-limited, then an ideal low-pass filter with gain T for $-\pi/T \le \omega \le \pi/T$ and zero elsewhere would recover $R(j\omega)$ from $R^*(j\omega)$ exactly.

If we define the ideal low-pass filter characteristic as $L(j\omega)$, we have:

$$R(j\omega) = L(j\omega)R^*(j\omega).$$

The signal r(t) is the inverse Fourier transform of $R(j\omega)$. Because $R(j\omega)$ is the *product* of two Fourier transforms, r(t) is the *convolution* of the time functions $\ell(t)$ and $r^*(t)$.

$$r(t) = \ell(t) * r^*(t)$$



Ideal low-pass filter

The impulse response of the filter can be computed using this definition

$$\ell(t) = \frac{1}{2\pi} \int_{-\pi/T}^{\pi/T} T e^{j\omega t} d\omega$$

$$= \frac{T}{2\pi} \frac{e^{j\omega t}}{jt} \Big|_{-\pi/T}^{\pi/T}$$

$$= \frac{T}{2\pi jt} (e^{j(\pi t/T)} - e^{-j(\pi t/T)})$$

$$= \frac{\sin(\pi t/T)}{\pi t/T}$$

$$\triangleq \operatorname{sinc} \frac{\pi t}{T}$$

The sinc functions are the interpolators that fill in the time gaps between samples with a signal that has no frequencies above π/T .

Reconstruction

Using the previous equations, we find:

$$r(t) = \int_{-\infty}^{\infty} r(\tau) \sum_{k=-\infty}^{\infty} \delta(\tau - kT) sinc \frac{\pi(t-\tau)}{T} d\tau$$
.

Using the shifting property of the impulse, we have:

$$r(t) = \sum_{k=-\infty}^{\infty} r(kT) sinc \frac{\pi(t-kT)}{T}$$

This equation is a constructive statement of the sampling theorem. There is one disadvantage. Because $\ell(t)$ is nonzero for t<0, this filter is noncausal. $\ell(t)$ starts at $t=-\infty$ while the impulse that triggers it does not occur until t=0. The noncausality can be overcome by adding a phase lag, $e^{-j\omega\lambda}$, to $L(j\omega)$, which adds a delay to the filter and to the signals processed through it.

Zero-order hold

The transfer function of the zero-order hold was introduced as

$$ZOH(j\omega) = \frac{1-e^{-j\omega T}}{j\omega}.$$

We express this function in magnitude and phase form, to discover the frequency properties of $ZOH(j\omega)$.

We factor out $e^{-j\omega T/2}$ and multiply and divide by 2j:

$$ZOH(j\omega) = e^{-j\omega T/2} \left\{ \frac{e^{j\omega T/2} - e^{-j\omega T/2}}{2j} \right\} \frac{2j}{j\omega}$$
$$= Te^{-j\omega T/2} \frac{\sin(\omega T/2)}{\omega T/2}$$
$$= e^{-j\omega T/2} T \operatorname{sinc}(\omega T/2)$$

Zero-order hold

The magnitude function is

$$|ZOH(j\omega)| = T \left| sinc \frac{\omega T}{2} \right|$$

and the phase is

$$\angle ZOH(j\omega) = \frac{-\omega T}{2}$$

plus the 180° shifts where the sinc function changes sign.

Thus the effect of the zero-order hold is to introduce a phase shift of $\omega T/2$ (a time delay of T/2 seconds) and to multiply the gain by a function with the magnitude of $sinc(\omega T/2)$.

Zero-order hold

Spectrum of ideal filter



Spectrum of ZOH

