

# Outline

- 1 Introduction
- 2 Analysis of the sample and hold
- 3 Fourier transform
- 4 Spectrum of a sampled signal
  - Aliasing
  - Sampling theorem
  - Hidden oscillations
- 5 Data extrapolation (reconstruction)
- 6 Block-diagram analysis of sampled-data systems
  - General Approach
  - Examples

# Hidden oscillations

## Definition

There is the possibility that a signal contains some frequencies that the samples do not show at all.

Such signals, when they occur in digital control systems, are called **hidden oscillations**.

They can only occur at multiples of the Nyquist frequency ( $\pi/T$ ).


# Outline

- 1 Introduction
- 2 Analysis of the sample and hold
- 3 Fourier transform
- 4 Spectrum of a sampled signal
  - Aliasing
  - Sampling theorem
  - Hidden oscillations
- 5 Data extrapolation (reconstruction)**
- 6 Block-diagram analysis of sampled-data systems
  - General Approach
  - Examples

# Reconstruction

Sampling theorem: *under the right conditions* it is possible to recover a signal from its samples.

The figure to the right shows the spectrum of  $R(j\omega)$ . It is contained in the low-frequency part of  $R^*(j\omega)$ . Therefore, to recover  $R(j\omega)$  we need to process  $R^*(j\omega)$  through a low-pass filter and multiply by  $T$ .



## Reconstruction

If  $R(j\omega)$  has zero energy for frequencies in the bands above the Nyquist frequency, in other words  $R$  is band-limited, then an ideal low-pass filter with gain  $T$  for  $-\pi/T \leq \omega \leq \pi/T$  and zero elsewhere would recover  $R(j\omega)$  from  $R^*(j\omega)$  exactly.

If we define the ideal low-pass filter characteristic as  $L(j\omega)$ , we have:

$$R(j\omega) = L(j\omega)R^*(j\omega).$$

The signal  $r(t)$  is the inverse Fourier transform of  $R(j\omega)$ . Because  $R(j\omega)$  is the *product* of two Fourier transforms,  $r(t)$  is the *convolution* of the time functions  $\ell(t)$  and  $r^*(t)$ .

$$r(t) = \ell(t) * r^*(t).$$


## Ideal low-pass filter

The impulse response of the filter can be computed using this definition:

$$\begin{aligned}\ell(t) &= \frac{1}{2\pi} \int_{-\pi/T}^{\pi/T} T e^{j\omega t} d\omega \\ &= \frac{T}{2\pi} \frac{e^{j\omega t}}{jt} \bigg|_{-\pi/T}^{\pi/T} \\ &= \frac{T}{2\pi jt} (e^{j(\pi t/T)} - e^{-j(\pi t/T)}) \\ &= \frac{\sin(\pi t/T)}{\pi t/T} \\ &\triangleq \text{sinc} \frac{\pi t}{T}\end{aligned}$$

## Ideal low-pass filter

The sinc functions are the interpolators that fill in the time gaps between samples with a signal that has no frequencies above  $\pi/T$ .



## Reconstruction

Using the previous equations, we find:

$$r(t) = \int_{-\infty}^{\infty} r(\tau) \sum_{k=-\infty}^{\infty} \delta(\tau - kT) \text{sinc} \frac{\pi(t-\tau)}{T} d\tau.$$

Using the shifting property of the impulse, we obtain:

$$r(t) = \sum_{k=-\infty}^{\infty} r(kT) \text{sinc} \frac{\pi(t-kT)}{T}.$$

This filter is non-causal because  $\ell(t)$  is nonzero for  $t < 0$ .  $\ell(t)$  starts at  $t = -\infty$  while the impulse that triggers it does not occur until  $t = 0$ . The non-causality can be overcome by adding a phase lag,  $e^{-j\omega\lambda}$ , to  $L(j\omega)$ , which adds a delay to the filter and to the signals processed through it.



## Zero-order hold

The transfer function of the zero-order hold was introduced as

$$ZOH(j\omega) = \frac{1 - e^{-j\omega T}}{j\omega}.$$

We express this function in magnitude and phase form, to discover the frequency properties of  $ZOH(j\omega)$ .

We factor out  $e^{-j\omega T/2}$  and multiply and divide by  $2j$ :

$$\begin{aligned} ZOH(j\omega) &= e^{-j\omega T/2} \left\{ \frac{e^{j\omega T/2} - e^{-j\omega T/2}}{2j} \right\} \frac{2j}{j\omega} \\ &= T e^{-j\omega T/2} \frac{\sin(\omega T/2)}{\omega T/2} \\ &= e^{-j\omega T/2} T \operatorname{sinc}(\omega T/2) \end{aligned}$$

## Zero-order hold

The magnitude function is

$$|ZOH(j\omega)| = T \left| \text{sinc} \frac{\omega T}{2} \right|$$

and the phase is


$$\angle ZOH(j\omega) = \frac{-\omega T}{2}$$

plus the  $180^\circ$  shifts where the sinc function changes sign.


Thus the effect of the zero-order hold is to introduce a phase shift of  $\omega T/2$  (a time delay of  $T/2$  seconds) and to multiply the gain by a function with the magnitude of  $\text{sinc}(\omega T/2)$ .

# Zero-order hold

## Spectrum of ideal filter



## Spectrum of ZOH



## First-order hold

If the extrapolation is done by a first order polynomial, then the extrapolator is called a first-order hold and its transfer function is denoted  $FOH(s)$ .

$$FOH(s) = (1 - e^{-Ts}) \frac{Ts+1}{Ts^2}$$

